

XL SCAN

large-field scanning solution



XL SCAN Overview

XL SCAN Overview

- Joint development by
 - ACS Motion Control, Ltd.
 - SCANLAB GmbH
- Combining 30+ years' expertise in each of
 - solution for motion control
 - solution for laser scanning with galvanometer motors
- Target applications
 - Large-field marking, cutting, engraving
 - Glass and foil processing
 - Micromachining
 - Via-hole drilling on PCBs
 - etc.



XL SCAN Overview

large-field scanning solution

excelliSCAN and XY stage in synchronized motion by

- **High-precision trajectory planning with syncAXIS control software**
- **Motion distribution between scan head and stage by low-pass filtering**




XL SCAN Overview

XL SCAN offers

- **Unlimited Field of View**
- **Unlimited Job Duration**
- **High Throughput**
- **High Accuracy**
in particular, zero tracking error in sharp curves and no stitching errors
- **Highly Dynamic Processes without Stage Vibration**
- **Automatized Trajectory Planning and Laser Control**
in particular, simultaneous control of spot distance & pulse energy (or pulse length)

allowing users to exploit the **full potential** of machine setup.

XL SCAN Overview



Components of XL SCAN

Basic Setup

- SCANLAB component
- ACS component
- Common component
- External component left to the user's choice

XL SCAN Overview

**syncAXIS control
with syncAXIS.dll /
APIs for C++/C#**

syncAXIS API is an application programming interface (API) for developing user programs in the form of functions for simultaneous control of laser, excelliSCAN and XY stage. It includes planning and status monitoring of jobs.

SCANLAB RTC6

The RTC6 board is used for real-time control of the scan head, the laser and the signal for xy-stage via SL2-100 transmission protocol.

SLEC

The SCANLAB-EtherCAT Converter (SLEC) translates the signals from the scanner's SL2-100 protocol to an EtherCAT protocol. This can be read by ACS motion drive.

**ACS API /
ACS DLL**

ACS API / DLL is the software from ACS for controlling the motion drive. This is used for installation and configuration. It can also be used in the user program.

ACS Controller

The ACS controller is the master of the EtherCAT protocol. It computes corrections of the stage in real time for the suppression of inaccuracies due to vibrations, overdrives and so on.

ACS Drives

ACS Drives are the motion drives for physical axes.


Software tools for XL SCAN system setup

Software tools for XL SCAN system setup

- A) Ready-to-use installation project** (included in syncAXIS control SW package)
=> providing a command-line console tool for 1st-time test operation
- B) syncAXIS Configurator** (included in syncAXIS control SW package)
=> providing a GUI tool for parameter setting
- C) syncAXIS Viewer** (included in syncAXIS control SW package)
=> providing a GUI tool for simulation and offline parameter optimization
- D) syncAXIS.dll** (included in syncAXIS control SW package as its **core component**)
=> providing C++ and C# APIs for the development of user application programs
- E) Optional: ACS SPiiPlus SPC** (**NOT included** in syncAXIS control SW package)
=> providing a GUI for complete machine control

Software tools for XL SCAN system setup

A) Ready-to-use installation project providing a command-line console tool with examples for demo & quick start of syncAXIS



C:\syncAXIS-1.3-win32\example\Installation_Project_Build\Installation_Project.exe

```
#####
##      Welcome to the syncAXIS control Installation Project      ##
##      This program demonstrates the implementation of      ##
##      the syncAXIS control software for controlling XL SCAN.      ##
##      Before starting the program, make sure the syncAXISConfig.xml      ##
##      file is correctly set (i.e. adding the ACS controllers IP      ##
##          address and correction file path)      ##
##      and placed in a specified location or the execution directory.      ##
#####
Please choose one of the following options:
Enter 0: "Leave application". (EXIT)
Enter 1: "Initialize an instance from an XML file". (INIT)
Enter 2: "Check for correct laser configuration by firing the laser manually without any motion". (CHECK_LASER_FIRING)
Enter 3: "Execute a reference run with each scanner and stage to check for correct configuration". (REFERENCE_RUN)
Enter 4: "Mark a test pattern (SCANLAB logo) with the current settings". (TEST_MARKING)
Enter 5: "Execute marking of a scanner calibration grid in ScannerOnly-mode". (SCANNER_CALI)
Enter 6: "Execute marking of a stage calibration grid in StageOnly-mode". (STAGE_CALI)
Enter 7: "Mark a grid in combined motion for evaluation of combined accuracy". (COMBINED_ACCURACY)
Enter 8: "Draw a marking pattern for checking the laser delays". (CHECK_LASERDELAYS)
Enter 9: "Execute an accuracy test pattern consisting of a circle grid pattern in
        ScannerOnly and a cross grid pattern in StageOnly-mode that can be compared". (CHECK_CALIBRATIONS)
Enter 10: "Draw a marking pattern for checking the system delays (should be good by default.
        Please contact SCANLAB in case they are not)". (CHECK_SYSTEMDELAYS)
Enter 11: "Change settings of the job like speed, offset, etc.". (CHANGE_SETTINGS)
Enter 12: "Delete instance without terminating the application". (DELETE_INSTANCE)
Enter 13: "Check for errors". (CHECK_FOR_ERRORS)
Please enter:
```

Software tools for XL SCAN system setup

B) syncAXIS Configurator providing a GUI tool

helping the user creating XML configuration file for syncAXIS

=> *in particular, parameter setting for scanner-stage motion distribution amongst others*

The screenshot shows the syncAXIS Configurator software interface. On the left is a navigation sidebar with buttons for General Configuration, RTC Configuration, Scan Device Configuration (which is highlighted in pink), Laser Configuration, IO Configuration, Trajectory Configuration, Stage Configuration, and Motion Decomposition. The main window has a title bar "syncAXIS Configurator - V1.2.5.2" with standard file operations like New, Open, Save, Undo, Redo, and a "Show XML" button. Below the title bar is a status bar showing "NewConfig19.05.28-09:23:1837". The central area is titled "Scan Device Configuration". It contains several configuration fields: "Dynamic Limits" (Off), "Field Limits" (Off), "Monitoring Level" (Deactivated), "Max Galvo Angle" (11.7 rad), "Focal Length" (100 mm), and "Delay" (1.25e-3 s). Below these are sections for "Scan Devices" (Count of Devices: 1) and "Scan Device 1" (Scan Device Name: ScanDevice1, Correction Files, Alignment: Off, Base Part Displacement: Off). At the bottom is a "Default Correction File" dropdown set to 0. To the right of the configuration window is a large block of XML code:


```

<?xml version="1.0"?>
<cfg:Configuration xmlns:xsi="http://www.w3.org/2001/XMLSchema-instance" xsi:schemaLocation="http://www.scanlab.de/syncaxis/v1.2.5.2/Configuration.xsd">
  <cfg:GeneralConfig>
    <cfg:ACSCController>0.0.0.0</cfg:ACSCController>
    <cfg:InitialOperationMode>ScannerAndStage</cfg:InitialOperationMode>
    <cfg:InitialListHandlingMode>ReturnAtOnce</cfg:InitialListHandlingMode>
    <cfg:DynamicViolationReaction>WarningOnly</cfg:DynamicViolationReaction>
    <cfg:LogConfig>
      <cfg:LogfilePath>Error.log</cfg:LogfilePath>
      <cfg:LogLevel>Warn</cfg:LogLevel>
      <cfg:EnableConsoleLogging>false</cfg:EnableConsoleLogging>
      <cfg:EnableFilelogging>true</cfg:EnableFilelogging>
      <cfg:MaxFileSize>5242880</cfg:MaxFileSize>
      <cfg:MaxBackupFileCount>10</cfg:MaxBackupFileCount>
    </cfg:LogConfig>
    <cfg:BaseDirectoryPath />
  </cfg:GeneralConfig>
  <cfg:RTCConfig>
    <cfg:BoardIdentificationMethod>UseFirstFound</cfg:BoardIdentificationMethod>
    <cfg:ProgramFileDirectory />
    <cfg:Boards>
      <cfg:RTCA6>
        <cfg:SerialNumber>0</cfg:SerialNumber>
        <cfg:HeadA>ScanDevice1</cfg:HeadA>
        <cfg:HeadB>Stage1</cfg:HeadB>
      </cfg:RTCA6>
    </cfg:Boards>
  </cfg:RTCConfig>
  <cfg:ScanDeviceConfig>
    <cfg:MonitoringLevel>Deactivated</cfg:MonitoringLevel>
    <cfg:MaxGalvoAngle Unit="rad">11.7</cfg:MaxGalvoAngle>
    <cfg:FocalLength Unit="mm">100</cfg:FocalLength>
    <cfg:Delay Unit="s">0.00125</cfg:Delay>
    <cfg:ScanDeviceList>
      <cfg:ScanDevice Name="ScanDevice1">
        <cfg:CorrectionFileList>
    
```

Software tools for XL SCAN system setup

C) syncAXIS Viewer providing a GUI tool

for reviewing simulation results and offline parameter optimization without laser



Typical parameters to be optimized for minimized error and avoidance of limit breach:

- JumpSpeed & MarkSpeed
- Blending Mode & Parameters
- Stage Velocity, Acc., and Jerk
- FilterBandwidth*
- etc.

* : This parameter determines the motion path distribution between scanner and stage.

Software tools for XL SCAN system setup

Two choices for the user's application development:

Choice 1: writing an own application program by using the C++ or C# API provided in form of

D) syncAXIS.dll

=> recommendable to the users experienced in machine control SW development (in particular, in RTC programming)

or

Choice 2: kick-starting the immediate validation tests and prototyping by using the GUI of

E) ACS SPiiPlus SPC (optional and **not included in syncAXIS control SW package)**

=> recommendable to inexperienced users or those user who just want to save time and resources during the pre-development phase

=> syncAXIS.dll, syncAXIS Configurator, and syncAXIS Viewer are included in **ACS SPiiPlus SPC**.

=> **ACS SPiiPlus SPC** also offers an SDK for the user to write own applications programs.

Software tools for XL SCAN system setup

D) syncAXIS.dll (C++ and C# API)

API offers the following functions:

- Extensive configuration possibilities
- Defining, labeling, loading, and executing laser processing jobs
- Job status monitoring
- Registering event callbacks
- Simulation of job execution

Functions are categorized into


- A) configuration functions,*
- B) control functions,*
- C) job functions, and*
- D) utility functions*

Motion parameters to be set by the user

- Max. velocity of stage
- Max. acceleration of stage
- Max. jerk of stage
- Mark speed
- Jump speed
- Low-pass filter bandwidth for stage motion part
- etc.



Software tools for XL SCAN system setup

D) syncAXIS.dll (C++ and C# API) – overview of configuration & control functions



Software tools for XL SCAN system setup

D) syncAXIS.dll (C++ and C# API) – overview of job & utility functions




Software tools for XL SCAN system setup

E) ACS SPIiPlus SPC (optional and **not included** in syncAXIS control SW package)

Cf. [XL SCAN with SPIiPlusSPC - YouTube](#) and

<https://acsmotioncontrol.com/products/application-development/spipluspc/>



Why XL SCAN?

Why XL SCAN?

Achievability of **High Accuracy** + **High Throughput** together at the same time

- **High Accuracy** via:
 - Zero encoder delay error (in communication between scanner and stage)
 - Minimized contour error (i.e. deviation of actual traj. from set traj.) within the exploitable maximum dynamics of scanner and stage
 - No stitching errors
 - Velocity- and position-based automatic laser control without extrapolation error, i.e.,
 - the simultaneous control of spot distance & laser power (e.g. by analog control or pulse length)
 - features extreme fine-tuning in laser control such as laser power ramping and vector- or contour-dependent adjustment of spot distance
- **High Throughput** (up to 40 % more compared to conventional systems) via:
 - Highly dynamic processes without vibration of table
 - Parallelization of laser processing to be controlled by one single PC
=> by multi-(SW-)instance and multi-head extension features

How does XL SCAN work?

How does XL SCAN work?

The Major Challenge in usual **encoder-based On-the-Fly processing** is:

the trade-off between throughput and accuracy being unavoidable due to the following facts:

- Galvanometer scanners very rapid, but usually less accurate than stage (at typ. focal lengths ≥ 100 mm for instance)
- Stages usually very precise, but much slower than galvanometer scanners

=> Consequently, **encoder-based communication** between stage control and scanner control **necessarily leads to time lag and position deviation** between stage and scanner during acceleration and deceleration phases.

How does XL SCAN work?

Solution


- **Exact trajectory planning ahead of time** by syncAXIS control software, i.e.:
Planning of a velocity profile for a given geometry of marking path taking the boundary conditions and physical limitations (velocity, acceleration, and jerk limits) of both stage and scanners into account + jump duration calculation
 - **Automated decomposition of planned motion path** into stage and scanner parts with *perfect synchronization between the stage motion and scanner motion and *perfect synchronization to laser control
- * : due to the complete knowledge about the future trajectory

allowing for



- the optimization of acceleration and velocity profile for the highest precision and **maximal exploitation of the system's dynamic potential**
=> result: “**set trajectory = actual trajectory**” within the given dynamic limits
- the adaptation of laser control (spot distance and pulse energy) to the velocity and acceleration profile at every position along the trajectory

How does XL SCAN work?

Motion Path Decomposition




Motion path decomposition works with a filter assigning
⇒ low-freq. motions to the stage
⇒ high-freq. motions to the scanner



How does XL SCAN work?

Motion Path Decomposition

With **adjustable low-pass filter bandwidth** to vary the motions assigned to scanner and stage




Depending on the process constraints, users may set their aim at:


- minimized work load on the stage load in order to reduce inaccuracies possibly resulting from vibrations of the stage
- minimized area of utilization within the scanner's field of view in order to reduce inaccuracies possibly resulting from focusing optics and/or imperfections in scanner's field calibration
- minimized process time by max. utilization the scanners' and stage's dynamic capabilities.

How does XL SCAN work?


Motion Path Decomposition (Example with $f = 100\text{mm}$ f-theta optics providing $\text{FoV} = 54\text{mm}$)




Scanner Motion @ FilterBandwidth = 1.5 Hz



Stage Motion @ FilterBandwidth = 1.5 Hz



Scanner Motion @ FilterBandwidth = 2.1 Hz



Stage Motion @ FilterBandwidth = 2.1 Hz

Test at SCANLAB

Test at SCANLAB

Scan system specifications

Scanner: excelliSCAN 14

Focusing optics: f = 100 mm telecentric f-theta objective

Field of view: 54 mm x 54 mm

Dynamics: $v_{max.} = 20 \text{ m/s}$

$a_{max.} = 32\,000 \text{ m/s}^2$

Dynamic following error: typ. 3 µm (conservative estimation*)

* : valid for acceleration-limited control by standard RTC6.dll

Note that the value depends on focal length and the utilized area within the FoV (i.e., the distance from the FoV center).

XY stage specifications

Field of motion: 300 mm x 300 mm

Dynamics: $v_{max.} = 1 \text{ m/s}$

$a_{max.} = 10 \text{ m/s}^2$

$j_{max.} = 100 \text{ m/s}^3$

Dynamic following error: typ. 1.5 µm (conservative estimation**)

** : valid for the case of utilizing the max. stage dynamics

Test at SCANLAB

Static error of scanner

	x-axis	y-axis	radial
Min.	-2.0 µm	-5.0 µm	0.0 µm
Max.	5.0 µm	1.0 µm	5.4 µm *
Standard deviation	1.3 µm	1.1 µm	1.4 µm
Mean	0.9 µm	-0.7 µm	1.6 µm

* : Imperfections in the scanner's field calibration and in the stage's error mapping were left to remain as they were.

Accuracy achieved in synchronized motion

	x-axis	y-axis	radial
Min.	-7.8 µm	-9.7 µm	0.0 µm
Max.	8.9 µm	4.1 µm	11.0 µm **
Standard deviation	2.9 µm	3.1 µm	2.6 µm
Mean	-0.8 µm	-3.5 µm	4.9 µm

Stage motion: meander-shaped pattern

Scanner motion: p-to-p jumps in zig-zag pattern


Grid points in 288 mm x 288 mm

Stage dynamics: 50% reached

Field of view: 75 % utilized

Static error of XY stage

	x-axis	y-axis	radial
Min.	-4.2 µm	-5.1 µm	0.0 µm
Max.	6.1 µm	4.7 µm	6.6 µm *
Standard deviation	1.6 µm	1.8 µm	1.2 µm
Mean	0.1 µm	0.8 µm	2.2 µm



** : approx. equal to the sum of scanner's and stage's static errors

Test at SCANLAB

Accuracy achieved in synchronized motion

	x-axis	y-axis	radial
Min.	-7.8 µm	-9.7 µm	0.0 µm
Max.	8.9 µm	4.1 µm	11.0 µm **
Standard deviation	2.9 µm	3.1 µm	2.6 µm
Mean	-0.8 µm	-3.5 µm	4.9 µm

Stage motion: meander-shaped pattern

Scanner motion: p-to-p jumps in zig-zag pattern

Grid points in 288 mm x 288 mm

Stage dynamics: 50% reached

Field of view: 75 % utilized

mark speed: 1 m/s @ f = 100 mm

jump speed: 1 m/s @ f = 100 mm

** : approx. equal to the sum of scanner's and stage's static errors

Test at SCANLAB

CONCLUSION:

Limit to the total accuracy of XL SCAN

$$= \text{StatErr}_{\text{scanner}} + \text{StatErr}_{\text{stage}}$$

(i.e. the sum of STATIC pos. errors)

No additional error contributions are present in XL SCAN

such as

- dynamic following errors
- any encoder-induced errors (such as those resulting from tracking delay in case of feedback-based scanner-stage synchronization)
- etc.


due to **exact trajectory planning (based on jerk-limited control)** and
appropriate motion distribution between scanner and stage

**Test in collaboration with
Pulsar Photonics and Holo/Or**

Test in collaboration with Pulsar Photonics and Holo/Or

Accuracy Evaluation in multi-beam jump-and-shoot tests

=> cf. [Variable multibeam tool enables high accuracy and throughput | Laser Focus World](#)



Comparison between two setups in their positioning accuracy

First setup:

- standard scan head with a focal length of 100 mm **without a stage operating in synchronization to the scan head**
- The positioning of the spots was carried out with ample time between the shots in order for the galvanometer mirrors to settle into their position. This is a quasi-static approach
- The position error was measured using a coordinate measurement machine


Second setup:

- combined processing using a scan head with focal length of 100 mm and a synchronized mechanical stage (**XL SCAN**)
- 10,000 shots fired at the workpiece
- The positioning occurs with a processing rate of 2600 Hz and is therefore highly dynamical

Test in collaboration with Pulsar Photonics and Holo/Or

Accuracy Evaluation in multi-beam jump-and-shoot tests


=> cf. [Variable multibeam tool enables high accuracy and throughput | Laser Focus World](#)



ScannerOnly Mode: position deviation is increasing with the radial position from approx. $2\mu\text{m}$ to approx. $4\mu\text{m}$.

Combined Mode: 99.99% (4σ) show a position error below $1.5\mu\text{m}$.

This shows how the combination with a synchronized stage can not only increase the processing area but also improve the position accuracy.



Achievability of High Accuracy

Achievability of High Accuracy

- **Demonstrated with test results**

- Trajectory planning ensures **ZERO** additional dynamic error.
- **No feedback loop is necessary**

With conventional control

- Commanded set points can demand accelerations / jerks that are physically impossible to achieve (e.g. acceleration limit due to the limitation on the available current)
- Result: actual position will not be equal to the set-point position during acceleration and will need time to minimize discrepancy after acceleration


With trajectory planning

- Algorithm ensures that dynamic limitations will not be breached
- Result: only set-points that are possible to be reached in iteration are commanded


- **Additional information**

- Stage has internal feedback loop.
- Galvanometer scanner has internal feedback loop.
- A feedback loop between stage and scan head would have a time lag that would prevent precision machining. For instance, 10ms time lag would lead to 300mm deviation at 30m/s scan speed.

Pos. error due to timelag in feedback-loop-based control



Demanded jerk and/or acc.would exceed the system's capabilities.






Actual positions are equal to set positions in trajectory-planning-based control. No correction needed

Further Tests at SCANLAB

Further Tests at SCANLAB

Throughput improvement




Application	Time (tiling/stitching and scan)	Time (combined motion)	Percentage saved
Circles	5.63 s	3.30 s	41%
Diamond shaped pattern	3.92 s	2.96 s	24%
Hole drilling (jump & shoot)	5.2 s (estimated)	4.42 s for 10,000 holes	15%
Hole drilling (repeated circles / trepanning)	12,2 s (estimated)	11,86 s for 5,000 holes	2 %

Cf. www.youtube.com/watch?v=CeAe0mbYMUE


Further Tests at SCANLAB

Stitching error check in diamond shaped pattern

The need for dividing working fields into individual tiles is with XL SCAN abolished. Risk for stitching errors is eliminated with all-in-one processing.



**Large field scanning
with “Stitch and Scan”**



**Large field scanning
with XL SCAN**



Cf. www.youtube.com/watch?v=CeAe0mbYMUE

Further Tests at SCANLAB

Examination of vibrations

Tests at two different filter bandwidths

- The larger filter bandwidth, the larger and more aggressive motion portion assigned to the stage
- However, no negative effect from increased vibrations visible for motions executed with larger filter bandwidth (thanks to trajectory planning / jerk-limited control)




Cf. www.youtube.com/watch?v=CeAe0mbYMUE

Example features providing benefits to the users

Example features providing benefits to the users

Example Feature 1: Blending

- Full control of „blending“ at a corner with small radius of curvature
- Define in metric units the accuracy of corner
- Possibility to tune accuracy vs. velocity
- Full control of laser energy in corner (see next slide)



Example features providing benefits to the users

Example Feature 2: Automatic Laser Control

- Simultaneous control of spot distance (“Spot Distance Control”) and pulse energy (“Power ramping”)
- Possibility to keep the laser exposure constant along the user-defined spot positions
- Speed-dependent ramping of laser parameters
- Vector- & intravector-defined ramping of laser parameters
- Deflection-angle-dependent control of laser parameters
=> enabling to keep the energy density distribution constant despite the spot size variations resulting from non-telecentric f-theta optics



The applicability of precise Spot Distance Control feature is only given for lasers equipped with external trigger functionality (a.k.a. “pulse-on-demand”).



Example features providing benefits to the users

Example Feature 2: Automatic Laser Control

Spot Distance Control (SDC)

- **As Standard Feature of RTC6 + excelliSCAN**
=> available even outside of XL SCAN package
=> based on feedback position from scanner which makes high-accuracy spot positioning very challenging in the phases of high acceleration and deceleration
- **As Standard Feature of XL SCAN (SDC based on trajectory planning in syncAXIS)**
=> significantly more accurate spot positioning based on the real spot speed on the workpiece
=> interpolation in 10µs cycle at 64MHz resolution
=> Example: max. spot distance variation of +/- 2.5% at the pulse repetition. rate of 800 kHz

regardless of acceleration or deceleration



Example features providing benefits to the users



Example Feature 2: Automatic Laser Control

Spot Distance Control (SDC)


Operation Mode: contour-dependent SDC

=> Constant spot distance can be defined

- either for the center of the spot
- or for the edge of the spot that meets the work piece.



Spot distance kept constant along the middle of laser spot's track



Spot distance kept constant along the edge of laser spot's track lying on the workpiece side (opposite to the waste side)

Example features providing benefits to the users


Example Feature 2: Automatic Laser Control

Laser Power Ramping (vector- & intravector-defined control)

=> Control signals can be ramped according to the user' demands along

- straight marking path or
- curved marking path or
- jumps

for two different laser control signals
individually.



*This is just one example for pulse energy adjustment.
Spot distance adjustment is also possible.*


Example features providing benefits to the users

Example Feature 2: Automatic Laser Control

Deflection-Angle-Dependent Laser Control

=> Deflection-angle-dependent laser control serves the purpose of keeping the energy density constant through out the entire field of view of the scan head, even if spot size varies along laser paths.



*This is just **one example** for pulse energy adjustment. Spot distance adjustment is also possible.*



Example features providing benefits to the users

Example Feature 3: Multi-Head Option

- => Available for up to max. 4 scan heads working in the same motion pattern
- => Each scan head's center positioning (in XY-plane) freely selectable
- => Adjustable workpiece orientation for each scan head




Possible Configurations


Possible Configurations of XL SCAN

A. Configurations with Single Software Instance and Single Scan Head

A-1. with Single Stage



A-2. with Multiple Stages




Single Software Instance with
Single Scan Head
Single RTC6 + Single SLEC
Single Stage

Single Software Instance with
Single Scan Head
Single RTC6 + Single SLEC
Multiple Stages


Possible Configurations of XL SCAN

B. Configurations with Multiple Software Instances and Multiple Scan Heads (BUT 1 Scan Head per Instance)

B-1. with Single Stage



B-2. with Multiple Stages




Multiple Software Instances with
Multiple Scan Heads (1 Scan Head per Instance)
Multiple RTC6s + Multiple SLECs (1 SLEC per RTC6)
Single Stage per Scan Head

Multiple Software Instances with
Multiple Scan Heads (1 Scan Head per Instance)
Multiple RTC6s + Multiple SLECs (1 SLEC per RTC6)
Multiple Stages per Scan Head

Possible Configurations of XL SCAN

C1. Configurations with Single Software Instance and 2 Scan Heads per Instance

Note: Each RTC6 board is equipped with two scan head connectors (for comm. via SL2-100 protocol).




**Single Software Instance with
2 Scan Heads + 2 RTC6s + 1 SLEC + Single Stage
per Instance**

Possible Configurations of XL SCAN

C2. Configurations with Single Software Instance and 3 Scan Heads per Instance

Note: Each RTC6 board is equipped with two scan head connectors (for comm. via SL2-100 protocol).




**Single Software Instance with
3 Scan Heads + 2 RTC6s + 1 SLEC + Single Stage
per Instance**

Possible Configurations of XL SCAN

C3. Configurations with Single Software Instance and 4 Scan Heads per Instance

Note: Each RTC6 board is equipped with two scan head connectors (for comm. via SL2-100 protocol).



**Single Software Instance with
4 Scan Heads + 3 RTC6s + 1 SLEC + Single Stage
per Instance**

Further Information

Further Information

Product Overview:

www.scanlab.de/en/products/advanced-scanning-solutions/xl-scan

Product Brochure:

www.scanlab.de/sites/default/files/2020-07/20_XLSCAN_syncAXIS_scanning%20solution.pdf

Video:

www.youtube.com/watch?v=CeAe0mbYMUE

Further Reading:

www.photonics.com/Articles/Motion_Control_Solutions_for_High-Precision/a65146

www.laserfocusworld.com/lasers-sources/article/14201504/variable-multibeam-tool-enables-high-accuracy-and-throughput

Software Download Links:

www.scanlab.de/en/downloads/software/syncaxis

www.acsmotioncontrol.com/products/application-development/spipluspc/